



NOTE: A 5° SLOPED SILL TRIMMER MUST BE INSTALLED WHEN THE GLAZING POCKET OF THE WINDOW JOINERY IS POSITIONED BACK PAST THE LINE OF THE WALL FRAME

Designed by: S.L.	Checked by: D.L.	Approved by: B. D.	File name: PT-041.DWG	Date: 18/01/05	Scale: 1:2.5 on A4
PUTZ TECHNIK			Drawing Title: SILL (ALTERNATIVE OPTION 2)		
			Drawing Number: PT-041	Revision: 1	Sheet: 1/1